

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	METFORM 850 STMR7B00
User ID :	pb97604	Batch NO. :	MRM2500385
Print Interval :	50000 Tablets	Running Time :	03 Hour 30 Min 15 Sec
Total Counter :	400092	Total Running Time :	435 Hour 53 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	160	%	Manual ;	76	RPM
Filling Cam :		Cam C 8.5-14mm		Cam Range :	Min :	6.50 mm
Target Quantity :		2647059	Tablets		Max :	12.00 mm
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		80	Min	Supply Time ;	0.3	Sec
Lower Punch Interval Time(S2) ;		60	Min	Supply Time ;	0.3	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		1.00	kN			
				Stop Condition ;		
HSP :	30.0 %	20.03	kN	No		
HEP :	23.0 %	18.95	kN	Yes 10	Rotations 10	Tablets
HCP :	2.0 %	15.71	kN	Yes 15	Times	
Ref :		15.40	kN			
LCP :	2.0 %	15.10	kN	Yes 15	Times	
LEP :	23.0 %	11.86	kN	Yes 10	Rotations 10	Tablets
LSP :	30.0 %	10.78	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	5.81	kN	Min :	5.70	kN	Punch NO.;	7
SD :	0.60	%	Max :	5.89	kN	Punch NO.;	48
Mean Main Pressure :	15.30	kN	Min :	14.54	kN	Punch NO.;	7
SD :	1.90	%	Max :	16.11	kN	Punch NO.;	11
Filling Depth :	Increase ;	883	Times	Decrease ;	948	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	18	RPM	Capacity :	114480	Tablets/hour
Feeder : Status ;	Auto		Speed ;	29	RPM
Pre Upper Punch Position ;	2.50	mm			
Pre Lower Punch Position ;	6.89	mm	Pre Thickness ;	4.39	mm
Main Upper Punch Position ;	2.50	mm			
Main Lower Punch Position ;	5.95	mm	Main Thickness ;	3.45	mm
Filling Depth :	8.52	mm	Current Cam :	Cam C	
Main Air pressure :	0.802	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	19	Min			
Lower Punch Remain Time (S2):	1	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.32	kN		
	Max ;	0.37	kN	Max Punch ;	26
Lower Punch :	Average ;	0.12	kN		
	Max ;	0.16	kN	Max Punch ;	9
Ejection Force :	Average ;	0.06	kN		
	Max ;	0.09	kN	Max Punch ;	38

Tablet Data (N/A)

Total Counter :	400092	Tablets			
A.W.C Counter :	398379	Tablets			
HEP :	582 (0.1%)	Tablets	LEP :	76 (0.0%)	Tablets
GOOD :	397721 (99.8%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	METFORM 850 STMR7B00
User ID :	pb97604	Batch NO. :	MRM2500385
Print Interval :	50000 Tablets	Running Time :	03 Hour 30 Min 15 Sec
Total Counter :	400092	Total Running Time :	435 Hour 53 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	166	%	Manual ;	60	RPM
Filling Cam :		Cam C 8.5-14mm		Cam Range :	Min :	6.50 mm
Target Quantity :		2647059	Tablets		Max :	12.00 mm
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		80	Min	Supply Time ;	0.3	Sec
Lower Punch Interval Time(S2) ;		60	Min	Supply Time ;	0.3	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		1.00	kN			
				Stop Condition ;		
HSP :	30.0 %	20.94	kN	No		
HEP :	23.0 %	19.82	kN	Yes 10	Rotations 10	Tablets
HCP :	2.0 %	16.43	kN	Yes 15	Times	
Ref :		16.11	kN			
LCP :	2.0 %	15.79	kN	Yes 15	Times	
LEP :	23.0 %	12.41	kN	Yes 10	Rotations 10	Tablets
LSP :	30.0 %	11.28	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	6.35	kN	Min :	6.26	kN	Punch NO.;	4
SD :	0.70	%	Max :	6.46	kN	Punch NO.;	17
Mean Main Pressure :	15.94	kN	Min :	15.23	kN	Punch NO.;	4
SD :	2.30	%	Max :	17.16	kN	Punch NO.;	35
Filling Depth :	Increase ;	549	Times	Decrease ;	550	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	18	RPM	Capacity :	114480	Tablets/hour
Feeder : Status ;	Auto		Speed ;	30	RPM
Pre Upper Punch Position ;	2.50	mm			
Pre Lower Punch Position ;	6.99	mm	Pre Thickness ;	4.49	mm
Main Upper Punch Position ;	2.50	mm			
Main Lower Punch Position ;	6.00	mm	Main Thickness ;	3.50	mm
Filling Depth :	8.83	mm	Current Cam :	Cam C	
Main Air pressure :	0.802	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	19	Min			
Lower Punch Remain Time (S2):	1	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.32	kN		
	Max ;	0.37	kN	Max Punch ;	53
Lower Punch :	Average ;	0.12	kN		
	Max ;	0.16	kN	Max Punch ;	9
Ejection Force :	Average ;	0.06	kN		
	Max ;	0.09	kN	Max Punch ;	38

Tablet Data (N/A)

Total Counter :	400092	Tablets			
A.W.C Counter :	398379	Tablets			
HEP :	582 (0.1%)	Tablets	LEP :	76 (0.0%)	Tablets
GOOD :	397721 (99.8%)	Tablets			