

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	METFORM 850 STMR7B00
User ID :	ka98463	Batch NO. :	MRM2500385
Print Interval :	50000 Tablets	Running Time :	13 Hour 34 Min 59 Sec
Total Counter :	1550442	Total Running Time :	445 Hour 59 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	160	%	Manual ;	76	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		2647059	Tablets			
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		80	Min	Supply Time ;	0.3	Sec
Lower Punch Interval Time(S2) ;		60	Min	Supply Time ;	0.3	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		1.00	kN			
				Stop Condition ;		
HSP :	30.0 %	20.50	kN	No		
HEP :	23.0 %	19.40	kN	Yes 10	Rotations 10	Tablets
HCP :	2.0 %	16.09	kN	Yes 15	Times	
Ref :		15.77	kN			
LCP :	2.0 %	15.46	kN	Yes 15	Times	
LEP :	23.0 %	12.14	kN	Yes 10	Rotations 10	Tablets
LSP :	30.0 %	11.04	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	5.90	kN	Min :	5.83	kN	Punch NO.;	26
SD :	0.70	%	Max :	6.00	kN	Punch NO.;	13
Mean Main Pressure :	15.70	kN	Min :	15.05	kN	Punch NO.;	7
SD :	2.40	%	Max :	16.92	kN	Punch NO.;	13
Filling Depth :	Increase ;	959	Times	Decrease ;	1066	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	18	RPM	Capacity :	114480	Tablets/hour
Feeder : Status ;	Auto		Speed ;	29	RPM
Pre Upper Punch Position ;	2.50	mm			
Pre Lower Punch Position ;	6.89	mm	Pre Thickness ;	4.39	mm
Main Upper Punch Position ;	2.50	mm			
Main Lower Punch Position ;	5.95	mm	Main Thickness ;	3.45	mm
Filling Depth :	8.53	mm	Current Cam :	Cam C	
Main Air pressure :	0.813	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	60	Min			
Lower Punch Remain Time (S2):	2	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.35	kN		
	Max ;	0.40	kN	Max Punch ;	52
Lower Punch :	Average ;	0.13	kN		
	Max ;	0.18	kN	Max Punch ;	12
Ejection Force :	Average ;	0.06	kN		
	Max ;	0.10	kN	Max Punch ;	35

Tablet Data (N/A)

Total Counter :	1550442	Tablets			
A.W.C Counter :	1547988	Tablets			
HEP :	621 (0.0%)	Tablets	LEP :	129 (0.0%)	Tablets
GOOD :	1547238 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	METFORM 850 STM7B00
User ID :	ka98463	Batch NO. :	MRM2500385
Print Interval :	50000 Tablets	Running Time :	13 Hour 34 Min 59 Sec
Total Counter :	1550442	Total Running Time :	445 Hour 59 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	166	%	Manual ;	60	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		2647059	Tablets			
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		80	Min	Supply Time ;	0.3	Sec
Lower Punch Interval Time(S2) ;		60	Min	Supply Time ;	0.3	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		1.00	kN			
				Stop Condition ;		
HSP :	30.0 %	21.46	kN	No		
HEP :	23.0 %	20.30	kN	Yes 10	Rotations 10	Tablets
HCP :	2.0 %	16.84	kN	Yes 15	Times	
Ref :		16.51	kN			
LCP :	2.0 %	16.18	kN	Yes 15	Times	
LEP :	23.0 %	12.71	kN	Yes 10	Rotations 10	Tablets
LSP :	30.0 %	11.55	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	6.54	kN	Min :	6.45	kN	Punch NO.;	43
SD :	0.70	%	Max :	6.65	kN	Punch NO.;	48
Mean Main Pressure :	16.43	kN	Min :	15.64	kN	Punch NO.;	46
SD :	2.50	%	Max :	17.39	kN	Punch NO.;	49
Filling Depth :	Increase ;	611	Times	Decrease ;	631	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	18	RPM	Capacity :	114480	Tablets/hour
Feeder : Status ;	Auto		Speed ;	30	RPM
Pre Upper Punch Position ;	2.50	mm			
Pre Lower Punch Position ;	6.99	mm	Pre Thickness ;	4.49	mm
Main Upper Punch Position ;	2.50	mm			
Main Lower Punch Position ;	6.00	mm	Main Thickness ;	3.50	mm
Filling Depth :	8.80	mm	Current Cam :	Cam C	
Main Air pressure :	0.813	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	60	Min			
Lower Punch Remain Time (S2):	2	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.35	kN		
	Max ;	0.40	kN	Max Punch ;	24
Lower Punch :	Average ;	0.13	kN		
	Max ;	0.18	kN	Max Punch ;	12
Ejection Force :	Average ;	0.06	kN		
	Max ;	0.10	kN	Max Punch ;	35

Tablet Data (N/A)

Total Counter :	1550442	Tablets			
A.W.C Counter :	1547988	Tablets			
HEP :	621 (0.0%)	Tablets	LEP :	129 (0.0%)	Tablets
GOOD :	1547238	Tablets			
	(100.0%)				