

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	SETRA50MG STSH4A00
User ID :	ka98463	Batch NO. :	SHM2500450
Print Interval :	50000 Tablets	Running Time :	14 Hour 19 Min 08 Sec
Total Counter :	3702364	Total Running Time :	777 Hour 20 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	18	%	Manual ;	12	RPM
Filling Cam :		Cam B		Cam Range :	Min :	2.50 mm
		4.5-10mm			Max :	8.00 mm
Target Quantity :		6000000	Tablets			
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		200	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		180	Min	Supply Time ;	2.0	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		1.00	kN			
				Stop Condition ;		
HSP :	30.0 %	17.33	kN	No		
HEP :	25.0 %	16.66	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	13.59	kN	Yes 15	Times	
Ref :		13.33	kN			
LCP :	2.0 %	13.06	kN	Yes 15	Times	
LEP :	25.0 %	10.00	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	9.33	kN	No		
SD limit :	20.0 %			Yes		
Pre HSP		20.00	kN	Yes		
Mean Calculation range :	1 Rotations			Calculation Pass :	1	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	1.07	kN	Min :	0.99	kN	Punch NO.;	14
SD :	2.70	%	Max :	1.16	kN	Punch NO.;	75
Mean Main Pressure :	13.28	kN	Min :	11.79	kN	Punch NO.;	15
SD :	4.60	%	Max :	15.79	kN	Punch NO.;	75
Filling Depth :	Increase ;	1035	Times	Decrease ;	1062	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	258720	Tablets/hour
Feeder : Status ;	Auto		Speed ;	5	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	5.60	mm	Pre Thickness ;	2.61	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	4.54	mm	Main Thickness ;	1.55	mm
Filling Depth :	5.95	mm	Current Cam :	Cam B	
Main Air pressure :	0.798	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	170	Min			
Lower Punch Remain Time (S2):	126	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.15	kN		
	Max ;	0.20	kN	Max Punch ;	75
Lower Punch :	Average ;	0.10	kN		
	Max ;	0.11	kN	Max Punch ;	51
Ejection Force :	Average ;	0.11	kN		
	Max ;	0.14	kN	Max Punch ;	60

Tablet Data (N/A)

Total Counter :	3702364	Tablets			
A.W.C Counter :	3693608	Tablets			
HEP :	64 (0.0%)	Tablets	LEP :	35 (0.0%)	Tablets
GOOD :	3693509	Tablets			
	(100.0%)				

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	SETRA50MG STSH4A00
User ID :	ka98463	Batch NO. :	SHM2500450
Print Interval :	50000 Tablets	Running Time :	14 Hour 19 Min 08 Sec
Total Counter :	3702364	Total Running Time :	777 Hour 20 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	18	%	Manual ;	12	RPM
Filling Cam :		Cam B		Cam Range :	Min :	2.50 mm
Target Quantity :		4.5-10mm			Max :	8.00 mm
Air Pressure Low Limit :		6000000	Tablets			
Oil Lubrication :		0.400	MPa			
Upper Punch Interval Time(S1) ;		200	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		180	Min	Supply Time ;	2.0	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		1.00	kN			
				Stop Condition ;		
HSP :	30.0 %	18.24	kN	No		
HEP :	25.0 %	17.54	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	14.31	kN	Yes 15	Times	
Ref :		14.03	kN			
LCP :	2.0 %	13.75	kN	Yes 15	Times	
LEP :	25.0 %	10.53	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	9.82	kN	No		
SD limit :	20.0 %			Yes		
Pre HSP		20.00	kN	Yes		
Mean Calculation range :	1	Rotations		Calculation Pass :	1	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	1.24	kN	Min :	1.20	kN	Punch NO.;	16
SD :	1.40	%	Max :	1.28	kN	Punch NO.;	34
Mean Main Pressure :	14.13	kN	Min :	13.47	kN	Punch NO.;	21
SD :	2.60	%	Max :	14.84	kN	Punch NO.;	28
Filling Depth :	Increase ;	284	Times	Decrease ;	283	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	258720	Tablets/hour
Feeder : Status ;	Auto		Speed ;	5	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	5.60	mm	Pre Thickness ;	2.61	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	4.54	mm	Main Thickness ;	1.55	mm
Filling Depth :	5.90	mm	Current Cam :	Cam B	
Main Air pressure :	0.798	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	170	Min			
Lower Punch Remain Time (S2):	126	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.15	kN		
	Max ;	0.20	kN	Max Punch ;	75
Lower Punch :	Average ;	0.10	kN		
	Max ;	0.11	kN	Max Punch ;	34
Ejection Force :	Average ;	0.11	kN		
	Max ;	0.14	kN	Max Punch ;	13

Tablet Data (N/A)

Total Counter :	3702364	Tablets			
A.W.C Counter :	3693608	Tablets			
HEP :	64 (0.0%)	Tablets	LEP :	35 (0.0%)	Tablets
GOOD :	3693509 (100.0%)	Tablets			