

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	MET 500 MG,STEW1A00
User ID :	sj97904	Batch NO. :	EWM2508950
Print Interval :	50000 Tablets	Running Time :	06 Hour 05 Min 48 Sec
Total Counter :	1085774	Total Running Time :	1198 Hour 48 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	64	%	Manual ;	15	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		4500000	Tablets			
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		120	Min	Supply Time ;	1.5	Sec
Lower Punch Interval Time(S2) ;		120	Min	Supply Time ;	1.8	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	27.99	kN	No		
HEP :	25.0 %	26.91	kN	Yes	10 Rotations	10 Tablets
HCP :	2.0 %	21.96	kN	Yes	10 Times	
Ref :		21.53	kN			
LCP :	2.0 %	21.10	kN	Yes	10 Times	
LEP :	25.0 %	16.15	kN	Yes	10 Rotations	10 Tablets
LSP :	30.0 %	15.07	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	2.88	kN	Min :	2.70	kN	Punch NO.;	13
SD :	2.40	%	Max :	3.04	kN	Punch NO.;	9
Mean Main Pressure :	21.49	kN	Min :	20.21	kN	Punch NO.;	41
SD :	3.40	%	Max :	23.22	kN	Punch NO.;	21
Filling Depth :	Increase ;	47	Times	Decrease ;	40	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	178080	Tablets/hour
Feeder : Status ;	Auto		Speed ;	18	RPM
Pre Upper Punch Position ;	3.00	mm			
Pre Lower Punch Position ;	6.46	mm	Pre Thickness ;	3.46	mm
Main Upper Punch Position ;	3.00	mm			
Main Lower Punch Position ;	5.26	mm	Main Thickness ;	2.26	mm
Filling Depth :	7.96	mm	Current Cam :	Cam C	
Main Air pressure :	0.835	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	83	Min			
Lower Punch Remain Time (S2):	84	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.06	kN		
	Max ;	0.13	kN	Max Punch ;	30
Lower Punch :	Average ;	0.07	kN		
	Max ;	0.14	kN	Max Punch ;	7
Ejection Force :	Average ;	0.05	kN		
	Max ;	0.20	kN	Max Punch ;	14

Tablet Data (N/A)

Total Counter :	1085774	Tablets			
A.W.C Counter :	1079698	Tablets			
HEP :	10 (0.0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	1079688 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	MET 500 MG,STEW1A00
User ID :	sj97904	Batch NO. :	EWM2508950
Print Interval :	50000 Tablets	Running Time :	06 Hour 05 Min 48 Sec
Total Counter :	1085774	Total Running Time :	1198 Hour 48 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	71	%	Manual ;	20	RPM
Filling Cam :		Cam C 8.5-14mm		Cam Range :	Min :	6.50 mm
Target Quantity :		4500000	Tablets		Max :	12.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		120	Min	Supply Time ;	1.5	Sec
Lower Punch Interval Time(S2) ;		120	Min	Supply Time ;	1.8	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	26.55	kN	No		
HEP :	25.0 %	25.53	kN	Yes 10	Rotations 10	Tablets
HCP :	2.0 %	20.83	kN	Yes 10	Times	
Ref :		20.43	kN			
LCP :	2.0 %	20.02	kN	Yes 10	Times	
LEP :	25.0 %	15.32	kN	Yes 10	Rotations 10	Tablets
LSP :	30.0 %	14.30	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	2.99	kN	Min :	2.72	kN	Punch NO.;	13
SD :	3.70	%	Max :	3.26	kN	Punch NO.;	51
Mean Main Pressure :	20.69	kN	Min :	19.09	kN	Punch NO.;	44
SD :	4.00	%	Max :	22.86	kN	Punch NO.;	21
Filling Depth :	Increase ;	27	Times	Decrease ;	24	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	178080	Tablets/hour
Feeder : Status ;	Auto		Speed ;	20	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.39	mm	Pre Thickness ;	3.40	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.46	mm	Main Thickness ;	2.47	mm
Filling Depth :	7.15	mm	Current Cam :	Cam C	
Main Air pressure :	0.835	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	83	Min			
Lower Punch Remain Time (S2):	84	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.06	kN		
	Max ;	0.13	kN	Max Punch ;	30
Lower Punch :	Average ;	0.07	kN		
	Max ;	0.14	kN	Max Punch ;	7
Ejection Force :	Average ;	0.05	kN		
	Max ;	0.21	kN	Max Punch ;	14

Tablet Data (N/A)

Total Counter :	1085774	Tablets			
A.W.C Counter :	1079698	Tablets			
HEP :	10 (0.0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	1079688 (100.0%)	Tablets			