

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	PANTO 20 MG,STKQ1A00
User ID :	pb97604	Batch NO. :	KQM2502220
Print Interval :	50000 Tablets	Running Time :	08 Hour 57 Min 10 Sec
Total Counter :	1750978	Total Running Time :	1730 Hour 27 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	17	%	Manual ;	20	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		5500000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.600	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		40	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		15	Min	Supply Time ;	2.0	Sec
Powder Supply Time :		30.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	15.56	kN	No		
HEP :	25.0 %	14.96	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	12.20	kN	Yes 15	Times	
Ref :		11.97	kN			
LCP :	2.0 %	11.73	kN	Yes 15	Times	
LEP :	25.0 %	8.97	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	8.38	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	1	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	1.56	kN	Min :	1.22	kN	Punch NO.;	45
SD :	9.40	%	Max :	1.91	kN	Punch NO.;	57
Mean Main Pressure :	12.23	kN	Min :	10.45	kN	Punch NO.;	13
SD :	6.50	%	Max :	14.31	kN	Punch NO.;	57
Filling Depth :	Increase ;	898	Times	Decrease ;	879	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	25	RPM	Capacity :	195000	Tablets/hour
Feeder : Status ;	Auto		Speed ;	4	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	4.36	mm	Pre Thickness ;	1.37	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	3.60	mm	Main Thickness ;	0.61	mm
Filling Depth :	6.33	mm	Current Cam :	Cam B	
Main Air pressure :	0.790	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	32	Min			
Lower Punch Remain Time (S2):	11	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.15	kN		
	Max ;	0.22	kN	Max Punch ;	51
Lower Punch :	Average ;	0.12	kN		
	Max ;	0.21	kN	Max Punch ;	38
Ejection Force :	Average ;	0.02	kN		
	Max ;	0.04	kN	Max Punch ;	14

Tablet Data (N/A)

Total Counter :	1750978	Tablets			
A.W.C Counter :	1741188	Tablets			
HEP :	314 (0.0%)	Tablets	LEP :	321 (0.0%)	Tablets
GOOD :	1740553 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	PANTO 20 MG,STKQ1A00
User ID :	pb97604	Batch NO. :	KQM2502220
Print Interval :	50000 Tablets	Running Time :	08 Hour 57 Min 10 Sec
Total Counter :	1750978	Total Running Time :	1730 Hour 27 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	16	%	Manual ;	20	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		5500000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.600	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		40	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		15	Min	Supply Time ;	2.0	Sec
Powder Supply Time :		30.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	17.29	kN	No		
HEP :	25.0 %	16.63	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	13.57	kN	Yes 15	Times	
Ref :		13.30	kN			
LCP :	2.0 %	13.03	kN	Yes 15	Times	
LEP :	25.0 %	9.98	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	9.31	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	1	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	1.71	kN	Min :	1.35	kN	Punch NO.;	17
SD :	6.40	%	Max :	1.92	kN	Punch NO.;	23
Mean Main Pressure :	13.32	kN	Min :	10.42	kN	Punch NO.;	17
SD :	6.30	%	Max :	15.49	kN	Punch NO.;	57
Filling Depth :	Increase ;	767	Times	Decrease ;	707	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	25	RPM	Capacity :	195000	Tablets/hour
Feeder : Status ;	Auto		Speed ;	4	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	4.36	mm	Pre Thickness ;	1.37	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	3.63	mm	Main Thickness ;	0.64	mm
Filling Depth :	6.44	mm	Current Cam :	Cam B	
Main Air pressure :	0.790	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	32	Min			
Lower Punch Remain Time (S2):	11	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.15	kN		
	Max ;	0.22	kN	Max Punch ;	51
Lower Punch :	Average ;	0.12	kN		
	Max ;	0.21	kN	Max Punch ;	38
Ejection Force :	Average ;	0.01	kN		
	Max ;	0.04	kN	Max Punch ;	14

Tablet Data (N/A)

Total Counter :	1750978	Tablets			
A.W.C Counter :	1741188	Tablets			
HEP :	314 (0.0%)	Tablets	LEP :	321 (0.0%)	Tablets
GOOD :	1740553 (100.0%)	Tablets			