

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	SERTRA 50MG STSH4A00
User ID :	mr99799	Batch NO. :	SHM2502550
Print Interval :	50000 Tablets	Running Time :	17 Hour 06 Min 18 Sec
Total Counter :	4429114	Total Running Time :	1997 Hour 45 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	48	%	Manual ;	30	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		6000000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		80	Min	Supply Time ;	0.5	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	17.03	kN	No		
HEP :	25.0 %	16.38	kN	Yes 10	Rotations 20	Tablets
HCP :	1.5 %	13.30	kN	Yes 15	Times	
Ref :		13.10	kN			
LCP :	1.5 %	12.91	kN	Yes 15	Times	
LEP :	25.0 %	9.83	kN	No 35	Rotations 35	Tablets
LSP :	30.0 %	9.17	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	1	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	1.95	kN	Min :	1.84	kN	Punch NO.;	65
SD :	2.00	%	Max :	2.05	kN	Punch NO.;	51
Mean Main Pressure :	13.23	kN	Min :	11.42	kN	Punch NO.;	6
SD :	4.30	%	Max :	14.29	kN	Punch NO.;	37
Filling Depth :	Increase ; 182	Times	Decrease ; 149	Times			

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	258720	Tablets/hour
Feeder : Status ;	Auto		Speed ;	13	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	5.59	mm	Pre Thickness ;	2.60	mm
Main Upper Punch Position ;	3.00	mm			
Main Lower Punch Position ;	5.15	mm	Main Thickness ;	2.15	mm
Filling Depth :	6.32	mm	Current Cam :	Cam B	
Main Air pressure :	0.743	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	41	Min			
Lower Punch Remain Time (S2):	20	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Enable		Dust Collector :	On	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.15	kN		
	Max ;	0.28	kN	Max Punch ;	63
Lower Punch :	Average ;	0.06	kN		
	Max ;	0.11	kN	Max Punch ;	6
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	4429114	Tablets			
A.W.C Counter :	4422174	Tablets			
HEP :	7 (0.0%)	Tablets	LEP :	917 (0.0%)	Tablets
GOOD :	4421250 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	SERTRA 50MG STSH4A00
User ID :	mr99799	Batch NO. :	SHM2502550
Print Interval :	50000 Tablets	Running Time :	17 Hour 06 Min 18 Sec
Total Counter :	4429114	Total Running Time :	1997 Hour 45 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	42	%	Manual ;	30	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		6000000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		80	Min	Supply Time ;	0.5	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	17.20	kN	No		
HEP :	25.0 %	16.54	kN	Yes 10	Rotations 20	Tablets
HCP :	1.5 %	13.43	kN	Yes 15	Times	
Ref :		13.23	kN			
LCP :	1.5 %	13.03	kN	Yes 15	Times	
LEP :	25.0 %	9.92	kN	Yes 35	Rotations 35	Tablets
LSP :	30.0 %	9.26	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	1	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	SD :	1.90	kN	Min :	1.82	kN	Punch NO.;	14
		1.90	%	Max :	2.02	kN	Punch NO.;	32
Mean Main Pressure :	SD :	13.30	kN	Min :	12.12	kN	Punch NO.;	14
		3.70	%	Max :	14.87	kN	Punch NO.;	32
Filling Depth :	Increase ;	57	Times	Decrease ;	74	Times		

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	258720	Tablets/hour
Feeder : Status ;	Auto		Speed ;	12	RPM
Pre Upper Punch Position ;	3.00	mm			
Pre Lower Punch Position ;	5.49	mm	Pre Thickness ;	2.49	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.22	mm	Main Thickness ;	2.23	mm
Filling Depth :	5.83	mm	Current Cam :	Cam B	
Main Air pressure :	0.743	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	41	Min			
Lower Punch Remain Time (S2):	20	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Enable		Dust Collector :	On	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.15	kN		
	Max ;	0.32	kN	Max Punch ;	63
Lower Punch :	Average ;	0.06	kN		
	Max ;	0.11	kN	Max Punch ;	6
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	4429114	Tablets			
A.W.C Counter :	4422174	Tablets			
HEP :	7 (0.0%)	Tablets	LEP :	917 (0.0%)	Tablets
GOOD :	4421250 (100.0%)	Tablets			