

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	PANTO 40 MG,STKQ1B00
User ID :	pb97604	Batch NO. :	KQM2510440
Print Interval :	50000 Tablets	Running Time :	08 Hour 42 Min 41 Sec
Total Counter :	1650814	Total Running Time :	2999 Hour 11 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	74	%	Manual ;	45	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		2750000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		50	Min	Supply Time ;	2.0	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	10.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		3.00	kN			
Ejecting Force High Limit :		4.90	kN			
				Stop Condition ;		
HSP :	30.0 %	40.48	kN	No		
HEP :	25.0 %	38.93	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	31.76	kN	Yes 15	Times	
Ref :		31.14	kN			
LCP :	2.0 %	30.52	kN	Yes 15	Times	
LEP :	25.0 %	23.36	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	21.80	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	4.05	kN	Min :	3.56	kN	Punch NO.;	31
SD :	5.90	%	Max :	4.64	kN	Punch NO.;	60
Mean Main Pressure :	30.85	kN	Min :	27.77	kN	Punch NO.;	31
SD :	4.50	%	Max :	33.54	kN	Punch NO.;	60
Filling Depth :	Increase ;	546	Times	Decrease ;	510	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	24	RPM	Capacity :	221760	Tablets/hour
Feeder : Status ;	Auto		Speed ;	18	RPM
Pre Upper Punch Position ;	3.00	mm			
Pre Lower Punch Position ;	4.21	mm	Pre Thickness ;	1.21	mm
Main Upper Punch Position ;	3.00	mm			
Main Lower Punch Position ;	3.84	mm	Main Thickness ;	0.84	mm
Filling Depth :	4.56	mm	Current Cam :	Cam B	
Main Air pressure :	0.644	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	8	Min			
Lower Punch Remain Time (S2):	20	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.61	kN		
	Max ;	0.78	kN	Max Punch ;	21
Lower Punch :	Average ;	0.43	kN		
	Max ;	1.39	kN	Max Punch ;	72
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	1650814	Tablets			
A.W.C Counter :	1607743	Tablets			
HEP :	334 (0.0%)	Tablets	LEP :	1028 (0.1%)	Tablets
GOOD :	1606381 (99.9%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	PANTO 40 MG,STKQ1B00
User ID :	pb97604	Batch NO. :	KQM2510440
Print Interval :	50000 Tablets	Running Time :	08 Hour 42 Min 41 Sec
Total Counter :	1650814	Total Running Time :	2999 Hour 11 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	61	%	Manual ;	45	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		2750000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		50	Min	Supply Time ;	2.0	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	10.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		3.00	kN			
Ejecting Force High Limit :		4.90	kN			
				Stop Condition ;		
HSP :	30.0 %	34.08	kN	No		
HEP :	25.0 %	32.77	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	26.74	kN	Yes 15	Times	
Ref :		26.22	kN			
LCP :	2.0 %	25.69	kN	Yes 15	Times	
LEP :	25.0 %	19.66	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	18.35	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	1	Rotations		Calculation Pass :	1	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	SD :	3.64	kN	Min :	3.07	kN	Punch NO.;	75
		8.70	%	Max :	4.41	kN	Punch NO.;	6
Mean Main Pressure :	SD :	25.48	kN	Min :	20.23	kN	Punch NO.;	74
		8.10	%	Max :	29.61	kN	Punch NO.;	9
Filling Depth :	Increase ;	298	Times	Decrease ;	271	Times		

PRODUCTION REPORT

Operation Value

Disk Speed :	24	RPM	Capacity :	221760	Tablets/hour
Feeder : Status ;	Auto		Speed ;	15	RPM
Pre Upper Punch Position ;	3.00	mm			
Pre Lower Punch Position ;	4.20	mm	Pre Thickness ;	1.20	mm
Main Upper Punch Position ;	3.00	mm			
Main Lower Punch Position ;	3.85	mm	Main Thickness ;	0.85	mm
Filling Depth :	3.59	mm	Current Cam :	Cam B	
Main Air pressure :	0.644	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	8	Min			
Lower Punch Remain Time (S2):	20	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.61	kN		
	Max ;	0.78	kN	Max Punch ;	21
Lower Punch :	Average ;	0.44	kN		
	Max ;	1.38	kN	Max Punch ;	72
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	1650814	Tablets			
A.W.C Counter :	1607743	Tablets			
HEP :	334 (0.0%)	Tablets	LEP :	1028 (0.1%)	Tablets
GOOD :	1606381 (99.9%)	Tablets			