

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	MET 500 MG,STEW1A00
User ID :	rp98927	Batch NO. :	EWM2507850
Print Interval :	50000 Tablets	Running Time :	06 Hour 27 Min 22 Sec
Total Counter :	1150546	Total Running Time :	1090 Hour 31 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	50	%	Manual ;	15	RPM
Filling Cam :		Cam C 8.5-14mm		Cam Range :	Min :	6.50 mm
Target Quantity :		4500000	Tablets		Max :	12.00 mm
Air Pressure Low Limit :		0.600	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		60	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		10	Min	Supply Time ;	3.0	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	26.85	kN	No		
HEP :	25.0 %	25.81	kN	Yes	10 Rotations	10 Tablets
HCP :	2.0 %	21.06	kN	Yes	10 Times	
Ref :		20.65	kN			
LCP :	2.0 %	20.24	kN	Yes	10 Times	
LEP :	25.0 %	15.49	kN	Yes	10 Rotations	10 Tablets
LSP :	30.0 %	14.46	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	4.64	kN	Min :	4.43	kN	Punch NO.;	15
SD :	2.20	%	Max :	4.96	kN	Punch NO.;	52
Mean Main Pressure :	20.88	kN	Min :	19.74	kN	Punch NO.;	49
SD :	3.20	%	Max :	22.92	kN	Punch NO.;	35
Filling Depth :	Increase ;	208	Times	Decrease ;	183	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	0	Tablets/hour
Feeder : Status ;	Auto		Speed ;	14	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.35	mm	Pre Thickness ;	3.36	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.40	mm	Main Thickness ;	2.41	mm
Filling Depth :	8.03	mm	Current Cam :	Cam C 8.5-14mm	
Main Air pressure :	0.797	MPa			
Oil Lubrication status :					
Upper Punch Remain Time (S1):	26	Min			
Lower Punch Remain Time (S2):	2	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.21	kN		
	Max ;	0.28	kN	Max Punch ;	30
Lower Punch :	Average ;	0.08	kN		
	Max ;	0.12	kN	Max Punch ;	41
Ejection Force :	Average ;	0.03	kN		
	Max ;	0.05	kN	Max Punch ;	41

Tablet Data (N/A)

Total Counter :	1150546	Tablets			
A.W.C Counter :	1146183	Tablets			
HEP :	132 (0.0%)	Tablets	LEP :	360 (0.0%)	Tablets
GOOD :	1145691 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	MET 500 MG,STEW1A00
User ID :	rp98927	Batch NO. :	EWM2507850
Print Interval :	50000 Tablets	Running Time :	06 Hour 27 Min 22 Sec
Total Counter :	1150546	Total Running Time :	1090 Hour 31 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	50	%	Manual ;	15	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		4500000	Tablets			
Air Pressure Low Limit :		0.600	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		60	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		10	Min	Supply Time ;	3.0	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	26.35	kN	No		
HEP :	25.0 %	25.34	kN	Yes 10	Rotations 10	Tablets
HCP :	2.0 %	20.68	kN	Yes 10	Times	
Ref :		20.27	kN			
LCP :	2.0 %	19.87	kN	Yes 10	Times	
LEP :	25.0 %	15.20	kN	Yes 10	Rotations 10	Tablets
LSP :	30.0 %	14.19	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	4.67	kN	Min :	4.48	kN	Punch NO.;	23
SD :	1.90	%	Max :	4.93	kN	Punch NO.;	22
Mean Main Pressure :	20.46	kN	Min :	19.17	kN	Punch NO.;	46
SD :	3.90	%	Max :	22.63	kN	Punch NO.;	13
Filling Depth :	Increase ;	195	Times	Decrease ;	193	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	0	Tablets/hour
Feeder : Status ;	Auto		Speed ;	14	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.30	mm	Pre Thickness ;	3.31	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.40	mm	Main Thickness ;	2.41	mm
Filling Depth :	7.77	mm	Current Cam :	Cam C 8.5-14mm	
Main Air pressure :	0.797	MPa			
Oil Lubrication status :					
Upper Punch Remain Time (S1):	26	Min			
Lower Punch Remain Time (S2):	2	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.21	kN		
	Max ;	0.28	kN	Max Punch ;	30
Lower Punch :	Average ;	0.08	kN		
	Max ;	0.12	kN	Max Punch ;	41
Ejection Force :	Average ;	0.03	kN		
	Max ;	0.05	kN	Max Punch ;	41

Tablet Data (N/A)

Total Counter :	1150546	Tablets			
A.W.C Counter :	1146183	Tablets			
HEP :	132 (0.0%)	Tablets	LEP :	360 (0.0%)	Tablets
GOOD :	1145691 (100.0%)	Tablets			