

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	MET 500 MG,STEW1A00
User ID :	sj97904	Batch NO. :	EWM2510750
Print Interval :	50000 Tablets	Running Time :	02 Hour 31 Min 23 Sec
Total Counter :	450274	Total Running Time :	1377 Hour 31 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	82	%	Manual ;	15	RPM
Filling Cam :		Cam C 8.5-14mm		Cam Range :	Min :	6.50 mm
Target Quantity :		4500000	Tablets		Max :	12.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		30	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		30.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	30.07	kN	No		
HEP :	25.0 %	28.91	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	23.59	kN	Yes 15	Times	
Ref :		23.13	kN			
LCP :	2.0 %	22.67	kN	Yes 15	Times	
LEP :	25.0 %	17.35	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	16.19	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	3.57	kN	Min :	3.38	kN	Punch NO.;	31
SD :	2.90	%	Max :	3.81	kN	Punch NO.;	3
Mean Main Pressure :	23.40	kN	Min :	22.19	kN	Punch NO.;	46
SD :	3.00	%	Max :	25.13	kN	Punch NO.;	17
Filling Depth :	Increase ;	1513	Times	Decrease ;	1527	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	178080	Tablets/hour
Feeder : Status ;	Auto		Speed ;	23	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.32	mm	Pre Thickness ;	3.33	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.38	mm	Main Thickness ;	2.39	mm
Filling Depth :	7.77	mm	Current Cam :	Cam C	
Main Air pressure :	0.747	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	10	Min			
Lower Punch Remain Time (S2):	20	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Enable		Dust Collector :	On	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0
Lower Punch :	Average ;	0.09	kN		
	Max ;	0.14	kN	Max Punch ;	23
Ejection Force :	Average ;	0.05	kN		
	Max ;	0.19	kN	Max Punch ;	43

Tablet Data (N/A)

Total Counter :	450274	Tablets			
A.W.C Counter :	447210	Tablets			
HEP :	0 (0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	447210 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	MET 500 MG,STEW1A00
User ID :	sj97904	Batch NO. :	EWM2510750
Print Interval :	50000 Tablets	Running Time :	02 Hour 31 Min 23 Sec
Total Counter :	450274	Total Running Time :	1377 Hour 31 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	80	%	Manual ;	20	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		4500000	Tablets			
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		30	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		30.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	29.28	kN	No		
HEP :	25.0 %	28.16	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	22.97	kN	Yes 15	Times	
Ref :		22.52	kN			
LCP :	2.0 %	22.07	kN	Yes 15	Times	
LEP :	25.0 %	16.89	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	15.77	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	3.10	kN	Min :	2.89	kN	Punch NO.;	41
SD :	3.80	%	Max :	3.46	kN	Punch NO.;	51
Mean Main Pressure :	22.37	kN	Min :	20.59	kN	Punch NO.;	46
SD :	4.00	%	Max :	24.85	kN	Punch NO.;	40
Filling Depth :	Increase ;	911	Times	Decrease ;	977	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	28	RPM	Capacity :	178080	Tablets/hour
Feeder : Status ;	Auto		Speed ;	22	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.32	mm	Pre Thickness ;	3.33	mm
Main Upper Punch Position ;	3.00	mm			
Main Lower Punch Position ;	5.46	mm	Main Thickness ;	2.46	mm
Filling Depth :	7.52	mm	Current Cam :	Cam C	
Main Air pressure :	0.747	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	10	Min			
Lower Punch Remain Time (S2):	20	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Enable		Dust Collector :	On	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0
Lower Punch :	Average ;	0.09	kN		
	Max ;	0.14	kN	Max Punch ;	23
Ejection Force :	Average ;	0.05	kN		
	Max ;	0.19	kN	Max Punch ;	43

Tablet Data (N/A)

Total Counter :	450274	Tablets			
A.W.C Counter :	447263	Tablets			
HEP :	0 (0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	447263 (100.0%)	Tablets			