

## PRODUCTION REPORT

### Product Information

|                  |               |                      |                         |
|------------------|---------------|----------------------|-------------------------|
| Machine Name :   | VANTIX P720D  | Product Name :       | PANTO 20<br>MG,STKQ1A00 |
| User ID :        | pb97604       | Batch NO. :          | KQM2502220              |
| Print Interval : | 50000 Tablets | Running Time :       | 06 Hour 39 Min 07 Sec   |
| Total Counter :  | 1300774       | Total Running Time : | 1728 Hour 8 Min         |
| Station :        | Station 1     |                      |                         |

### Setting Value

|                                    |        |                   |         |                    |       |                      |
|------------------------------------|--------|-------------------|---------|--------------------|-------|----------------------|
| Feeder :                           | Auto ; | 17                | %       | Manual ;           | 20    | RPM                  |
| Filling Cam :                      |        | Cam B<br>4.5-10mm |         | Cam Range :        | Min : | 2.50 mm              |
| Target Quantity :                  |        | 5500000           | Tablets |                    | Max : | 8.00 mm              |
| Air Pressure Low Limit :           |        | 0.600             | MPa     |                    |       |                      |
| Oil Lubrication :                  |        |                   |         |                    |       |                      |
| Upper Punch Interval Time(S1) ;    |        | 40                | Min     | Supply Time ;      | 1.0   | Sec                  |
| Lower Punch Interval Time(S2) ;    |        | 15                | Min     | Supply Time ;      | 2.0   | Sec                  |
| Powder Supply Time :               |        | 30.0              | Sec     |                    |       |                      |
| Initial Reject Time :              |        | 1                 | Tablets |                    |       |                      |
| Upper Punch Tightness High Limit : |        | 2.00              | kN      |                    |       |                      |
| Lower Punch Tightness High Limit : |        | 4.00              | kN      |                    |       |                      |
| Ejecting Force High Limit :        |        | 4.00              | kN      |                    |       |                      |
|                                    |        |                   |         | Stop Condition ;   |       |                      |
| HSP :                              | 30.0 % | 16.52             | kN      | No                 |       |                      |
| HEP :                              | 25.0 % | 15.88             | kN      | Yes                | 10    | Rotations 15 Tablets |
| HCP :                              | 2.0 %  | 12.96             | kN      | Yes                | 15    | Times                |
| Ref :                              |        | 12.70             | kN      |                    |       |                      |
| LCP :                              | 2.0 %  | 12.45             | kN      | Yes                | 15    | Times                |
| LEP :                              | 25.0 % | 9.53              | kN      | Yes                | 10    | Rotations 15 Tablets |
| LSP :                              | 30.0 % | 8.89              | kN      | No                 |       |                      |
| SD limit :                         | 35.0 % |                   |         | Yes                |       |                      |
| Pre HSP                            |        | 30.00             | kN      | Yes                |       |                      |
| Mean Calculation range :           | 2      | Rotations         |         | Calculation Pass : | 1     | Rotations            |
| Empty Punch No. :                  | None   |                   |         |                    |       |                      |

### Pressure Data

|                      |            |       |       |            |       |       |            |    |
|----------------------|------------|-------|-------|------------|-------|-------|------------|----|
| Mean Pre Pressure :  | SD :       | 1.65  | kN    | Min :      | 1.24  | kN    | Punch NO.; | 26 |
|                      |            | 8.40  | %     | Max :      | 1.97  | kN    | Punch NO.; | 33 |
| Mean Main Pressure : |            | 12.56 | kN    | Min :      | 10.28 | kN    | Punch NO.; | 26 |
|                      | SD :       | 5.50  | %     | Max :      | 13.97 | kN    | Punch NO.; | 5  |
| Filling Depth :      | Increase ; | 741   | Times | Decrease ; | 734   | Times |            |    |

## PRODUCTION REPORT

### Operation Value

|                               |         |     |                  |          |              |
|-------------------------------|---------|-----|------------------|----------|--------------|
| Disk Speed :                  | 25      | RPM | Capacity :       | 195000   | Tablets/hour |
| Feeder : Status ;             | Auto    |     | Speed ;          | 4        | RPM          |
| Pre Upper Punch Position ;    | 2.99    | mm  |                  |          |              |
| Pre Lower Punch Position ;    | 4.36    | mm  | Pre Thickness ;  | 1.37     | mm           |
| Main Upper Punch Position ;   | 2.99    | mm  |                  |          |              |
| Main Lower Punch Position ;   | 3.60    | mm  | Main Thickness ; | 0.61     | mm           |
| Filling Depth :               | 6.18    | mm  | Current Cam :    | Cam B    |              |
| Main Air pressure :           | 0.768   | MPa |                  | 4.5-10mm |              |
| Oil Lubrication status :      |         |     |                  |          |              |
| Upper Punch Remain Time (S1): | 10      | Min |                  |          |              |
| Lower Punch Remain Time (S2): | 13      | Min |                  |          |              |
| Lower Head Remain Time (S3):  | 0       | Min |                  |          |              |
| Powder Status :               | Disable |     | Dust Collector : | Off      |              |
| Initial Reject :              | Off     |     | Buzzer :         | Off      |              |

### Tightness

|                  |           |      |    |             |    |
|------------------|-----------|------|----|-------------|----|
| Upper Punch :    | Average ; | 0.14 | kN |             |    |
|                  | Max ;     | 0.23 | kN | Max Punch ; | 14 |
| Lower Punch :    | Average ; | 0.13 | kN |             |    |
|                  | Max ;     | 0.24 | kN | Max Punch ; | 38 |
| Ejection Force : | Average ; | 0.02 | kN |             |    |
|                  | Max ;     | 0.04 | kN | Max Punch ; | 46 |

### Tablet Data (N/A)

|                 |                     |         |       |            |         |
|-----------------|---------------------|---------|-------|------------|---------|
| Total Counter : | 1300774             | Tablets |       |            |         |
| A.W.C Counter : | 1291284             | Tablets |       |            |         |
| HEP :           | 140 (0.0%)          | Tablets | LEP : | 119 (0.0%) | Tablets |
| GOOD :          | 1291025<br>(100.0%) | Tablets |       |            |         |

## PRODUCTION REPORT

### Product Information

|                  |               |                      |                         |
|------------------|---------------|----------------------|-------------------------|
| Machine Name :   | VANTIX P720D  | Product Name :       | PANTO 20<br>MG,STKQ1A00 |
| User ID :        | pb97604       | Batch NO. :          | KQM2502220              |
| Print Interval : | 50000 Tablets | Running Time :       | 06 Hour 39 Min 07 Sec   |
| Total Counter :  | 1300774       | Total Running Time : | 1728 Hour 8 Min         |
| Station :        | Station 2     |                      |                         |

### Setting Value

|                                    |        |                   |         |                    |       |                      |
|------------------------------------|--------|-------------------|---------|--------------------|-------|----------------------|
| Feeder :                           | Auto ; | 16                | %       | Manual ;           | 20    | RPM                  |
| Filling Cam :                      |        | Cam B<br>4.5-10mm |         | Cam Range :        | Min : | 2.50 mm              |
| Target Quantity :                  |        | 5500000           | Tablets |                    | Max : | 8.00 mm              |
| Air Pressure Low Limit :           |        | 0.600             | MPa     |                    |       |                      |
| Oil Lubrication :                  |        |                   |         |                    |       |                      |
| Upper Punch Interval Time(S1) ;    |        | 40                | Min     | Supply Time ;      | 1.0   | Sec                  |
| Lower Punch Interval Time(S2) ;    |        | 15                | Min     | Supply Time ;      | 2.0   | Sec                  |
| Powder Supply Time :               |        | 30.0              | Sec     |                    |       |                      |
| Initial Reject Time :              |        | 1                 | Tablets |                    |       |                      |
| Upper Punch Tightness High Limit : |        | 2.00              | kN      |                    |       |                      |
| Lower Punch Tightness High Limit : |        | 4.00              | kN      |                    |       |                      |
| Ejecting Force High Limit :        |        | 4.00              | kN      |                    |       |                      |
|                                    |        |                   |         | Stop Condition ;   |       |                      |
| HSP :                              | 30.0 % | 18.50             | kN      | No                 |       |                      |
| HEP :                              | 25.0 % | 17.79             | kN      | Yes                | 10    | Rotations 15 Tablets |
| HCP :                              | 2.0 %  | 14.52             | kN      | Yes                | 15    | Times                |
| Ref :                              |        | 14.23             | kN      |                    |       |                      |
| LCP :                              | 2.0 %  | 13.95             | kN      | Yes                | 15    | Times                |
| LEP :                              | 25.0 % | 10.67             | kN      | Yes                | 10    | Rotations 15 Tablets |
| LSP :                              | 30.0 % | 9.96              | kN      | No                 |       |                      |
| SD limit :                         | 35.0 % |                   |         | Yes                |       |                      |
| Pre HSP                            |        | 30.00             | kN      | Yes                |       |                      |
| Mean Calculation range :           | 2      | Rotations         |         | Calculation Pass : | 1     | Rotations            |
| Empty Punch No. :                  | N      |                   |         |                    |       |                      |

### Pressure Data

|                      |            |     |       |            |     |            |    |
|----------------------|------------|-----|-------|------------|-----|------------|----|
| Mean Pre Pressure :  | 1.83       | kN  | Min : | 1.50       | kN  | Punch NO.; | 17 |
| SD :                 | 6.40       | %   | Max : | 2.04       | kN  | Punch NO.; | 35 |
| Mean Main Pressure : | 14.27      | kN  | Min : | 11.80      | kN  | Punch NO.; | 17 |
| SD :                 | 6.00       | %   | Max : | 16.23      | kN  | Punch NO.; | 65 |
| Filling Depth :      | Increase ; | 719 | Times | Decrease ; | 662 | Times      |    |

## PRODUCTION REPORT

### Operation Value

|                               |         |     |                  |          |              |
|-------------------------------|---------|-----|------------------|----------|--------------|
| Disk Speed :                  | 25      | RPM | Capacity :       | 195000   | Tablets/hour |
| Feeder : Status ;             | Auto    |     | Speed ;          | 4        | RPM          |
| Pre Upper Punch Position ;    | 2.99    | mm  |                  |          |              |
| Pre Lower Punch Position ;    | 4.36    | mm  | Pre Thickness ;  | 1.37     | mm           |
| Main Upper Punch Position ;   | 2.99    | mm  |                  |          |              |
| Main Lower Punch Position ;   | 3.60    | mm  | Main Thickness ; | 0.61     | mm           |
| Filling Depth :               | 6.47    | mm  | Current Cam :    | Cam B    |              |
| Main Air pressure :           | 0.768   | MPa |                  | 4.5-10mm |              |
| Oil Lubrication status :      |         |     |                  |          |              |
| Upper Punch Remain Time (S1): | 10      | Min |                  |          |              |
| Lower Punch Remain Time (S2): | 13      | Min |                  |          |              |
| Lower Head Remain Time (S3):  | 0       | Min |                  |          |              |
| Powder Status :               | Disable |     | Dust Collector : | Off      |              |
| Initial Reject :              | Off     |     | Buzzer :         | Off      |              |

### Tightness

|                  |           |      |    |             |    |
|------------------|-----------|------|----|-------------|----|
| Upper Punch :    | Average ; | 0.14 | kN |             |    |
|                  | Max ;     | 0.23 | kN | Max Punch ; | 14 |
| Lower Punch :    | Average ; | 0.13 | kN |             |    |
|                  | Max ;     | 0.24 | kN | Max Punch ; | 38 |
| Ejection Force : | Average ; | 0.02 | kN |             |    |
|                  | Max ;     | 0.05 | kN | Max Punch ; | 14 |

### Tablet Data (N/A)

|                 |                     |         |       |            |         |
|-----------------|---------------------|---------|-------|------------|---------|
| Total Counter : | 1300774             | Tablets |       |            |         |
| A.W.C Counter : | 1291284             | Tablets |       |            |         |
| HEP :           | 140 (0.0%)          | Tablets | LEP : | 119 (0.0%) | Tablets |
| GOOD :          | 1291025<br>(100.0%) | Tablets |       |            |         |