

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	GLICLAZIDE MR 30MG
User ID :	pb97604	Batch NO. :	GLC TAB XV 25 003
Print Interval :	50000 Tablets	Running Time :	00 Hour 35 Min 50 Sec
Total Counter :	56838	Total Running Time :	1765 Hour 14 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	90	%	Manual ;	20	RPM
Filling Cam :		Cam B		Cam Range :	Min :	2.50 mm
		4.5-10mm			Max :	8.00 mm
Target Quantity :		1500000	Tablets			
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		60	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		40	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	14.95	kN	No		
HEP :	25.0 %	14.38	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	11.73	kN	Yes 15	Times	
Ref :		11.50	kN			
LCP :	2.0 %	11.27	kN	Yes 15	Times	
LEP :	25.0 %	8.63	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	8.05	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	SD :	1.33	kN	Min :	1.22	kN	Punch NO.;	9
		3.90	%	Max :	1.45	kN	Punch NO.;	39
Mean Main Pressure :		11.48	kN	Min :	10.66	kN	Punch NO.;	9
	SD :	3.30	%	Max :	12.55	kN	Punch NO.;	39
Filling Depth :	Increase ;	6	Times	Decrease ;	33	Times		

PRODUCTION REPORT

Operation Value

Disk Speed :	15	RPM	Capacity :	95400	Tablets/hour
Feeder : Status ;	Auto		Speed ;	14	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	5.32	mm	Pre Thickness ;	2.33	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	4.35	mm	Main Thickness ;	1.36	mm
Filling Depth :	5.37	mm	Current Cam :	Cam B	
Main Air pressure :	0.808	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	6	Min			
Lower Punch Remain Time (S2):	37	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.08	kN		
	Max ;	0.14	kN	Max Punch ;	35
Lower Punch :	Average ;	0.13	kN		
	Max ;	0.13	kN	Max Punch ;	51
Ejection Force :	Average ;	0.03	kN		
	Max ;	0.04	kN	Max Punch ;	15

Tablet Data (N/A)

Total Counter :	56838	Tablets			
A.W.C Counter :	48155	Tablets			
HEP :	0 (0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	48155 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	GLICLAZIDE MR 30MG
User ID :	pb97604	Batch NO. :	GLC TAB XV 25 003
Print Interval :	50000 Tablets	Running Time :	00 Hour 35 Min 50 Sec
Total Counter :	56838	Total Running Time :	1765 Hour 14 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	90	%	Manual ;	24	RPM
Filling Cam :		Cam B		Cam Range :	Min :	2.50 mm
		4.5-10mm			Max :	8.00 mm
Target Quantity :		1500000	Tablets			
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		60	Min	Supply Time ;	1.0	Sec
Lower Punch Interval Time(S2) ;		40	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		5.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		4.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	30.0 %	13.99	kN	No		
HEP :	25.0 %	13.46	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	10.98	kN	Yes 15	Times	
Ref :		10.77	kN			
LCP :	2.0 %	10.55	kN	Yes 15	Times	
LEP :	25.0 %	8.07	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	7.54	kN	No		
SD limit :	35.0 %			Yes		
Pre HSP		30.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	1.28	kN	Min :	1.17	kN	Punch NO.;	10
SD :	4.00	%	Max :	1.39	kN	Punch NO.;	35
Mean Main Pressure :	10.61	kN	Min :	10.04	kN	Punch NO.;	53
SD :	2.90	%	Max :	11.29	kN	Punch NO.;	8
Filling Depth :	Increase ; 11	Times	Decrease ; 18	Times			

PRODUCTION REPORT

Operation Value

Disk Speed :	15	RPM	Capacity :	95400	Tablets/hour
Feeder : Status ;	Auto		Speed ;	14	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	5.40	mm	Pre Thickness ;	2.41	mm
Main Upper Punch Position ;	2.98	mm			
Main Lower Punch Position ;	4.53	mm	Main Thickness ;	1.55	mm
Filling Depth :	5.71	mm	Current Cam :	Cam B	
Main Air pressure :	0.808	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	6	Min			
Lower Punch Remain Time (S2):	37	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.08	kN		
	Max ;	0.14	kN	Max Punch ;	35
Lower Punch :	Average ;	0.13	kN		
	Max ;	0.13	kN	Max Punch ;	51
Ejection Force :	Average ;	0.03	kN		
	Max ;	0.04	kN	Max Punch ;	32

Tablet Data (N/A)

Total Counter :	56838	Tablets			
A.W.C Counter :	48155	Tablets			
HEP :	0 (0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	48155 (100.0%)	Tablets			