

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	LER HCL20MG STDJ1B00
User ID :	sj97904	Batch NO. :	DJM2500520
Print Interval :	50000 Tablets	Running Time :	05 Hour 56 Min 07 Sec
Total Counter :	816388	Total Running Time :	2260 Hour 26 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	50	%	Manual ;	57	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		2550000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		35	Min	Supply Time ;	0.3	Sec
Lower Punch Interval Time(S2) ;		40	Min	Supply Time ;	2.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	25.0 %	13.16	kN	No		
HEP :	20.0 %	12.63	kN	Yes 10	Rotations 20	Tablets
HCP :	2.0 %	10.74	kN	Yes 15	Times	
Ref :		10.53	kN			
LCP :	2.0 %	10.32	kN	Yes 15	Times	
LEP :	20.0 %	8.42	kN	No 15	Rotations 20	Tablets
LSP :	25.0 %	7.90	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	2.48	kN	Min :	2.41	kN	Punch NO.;	34
SD :	1.10	%	Max :	2.56	kN	Punch NO.;	33
Mean Main Pressure :	10.57	kN	Min :	9.95	kN	Punch NO.;	18
SD :	2.70	%	Max :	11.18	kN	Punch NO.;	52
Filling Depth :	Increase ; 1	Times	Decrease ; 1	Times			

PRODUCTION REPORT

Operation Value

Disk Speed :	22	RPM	Capacity :	139920	Tablets/hour
Feeder : Status ;	Auto		Speed ;	11	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.10	mm	Pre Thickness ;	3.11	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.13	mm	Main Thickness ;	2.14	mm
Filling Depth :	5.90	mm	Current Cam :	Cam B	
Main Air pressure :	0.799	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	32	Min			
Lower Punch Remain Time (S2):	40	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Enable		Dust Collector :	On	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.28	kN		
	Max ;	0.37	kN	Max Punch ;	35
Lower Punch :	Average ;	0.06	kN		
	Max ;	0.08	kN	Max Punch ;	20
Ejection Force :	Average ;	0.04	kN		
	Max ;	0.05	kN	Max Punch ;	53

Tablet Data (N/A)

Total Counter :	816388	Tablets			
A.W.C Counter :	814053	Tablets			
HEP :	0 (0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	814053 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	LER HCL20MG STDJ1B00
User ID :	sj97904	Batch NO. :	DJM2500520
Print Interval :	50000 Tablets	Running Time :	05 Hour 56 Min 07 Sec
Total Counter :	816388	Total Running Time :	2260 Hour 26 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	50	%	Manual ;	30	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		2550000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.000	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		35	Min	Supply Time ;	0.3	Sec
Lower Punch Interval Time(S2) ;		40	Min	Supply Time ;	2.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		1.00	kN			
Lower Punch Tightness High Limit :		1.00	kN			
Ejecting Force High Limit :		4.00	kN			
				Stop Condition ;		
HSP :	25.0 %	13.54	kN	No		
HEP :	20.0 %	13.00	kN	Yes 15	Rotations 20	Tablets
HCP :	2.0 %	11.05	kN	Yes 20	Times	
Ref :		10.83	kN			
LCP :	2.0 %	10.62	kN	Yes 20	Times	
LEP :	20.0 %	8.67	kN	Yes 15	Rotations 20	Tablets
LSP :	25.0 %	8.13	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	2.73	kN	Min :	2.65	kN	Punch NO.;	2
SD :	1.30	%	Max :	2.82	kN	Punch NO.;	33
Mean Main Pressure :	10.82	kN	Min :	10.33	kN	Punch NO.;	29
SD :	2.40	%	Max :	11.33	kN	Punch NO.;	27
Filling Depth :	Increase ;	0	Times	Decrease ;	3	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	22	RPM	Capacity :	139920	Tablets/hour
Feeder : Status ;	Auto		Speed ;	11	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	6.00	mm	Pre Thickness ;	3.01	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	5.30	mm	Main Thickness ;	2.31	mm
Filling Depth :	6.00	mm	Current Cam :	Cam B	
Main Air pressure :	0.799	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	32	Min			
Lower Punch Remain Time (S2):	40	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Enable		Dust Collector :	On	
Initial Reject :	Off		Buzzer :	On	

Tightness

Upper Punch :	Average ;	0.28	kN		
	Max ;	0.37	kN	Max Punch ;	35
Lower Punch :	Average ;	0.06	kN		
	Max ;	0.07	kN	Max Punch ;	11
Ejection Force :	Average ;	0.04	kN		
	Max ;	0.05	kN	Max Punch ;	5

Tablet Data (N/A)

Total Counter :	816388	Tablets			
A.W.C Counter :	814053	Tablets			
HEP :	0 (0%)	Tablets	LEP :	0 (0%)	Tablets
GOOD :	814053 (100.0%)	Tablets			