

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	IBU BP600MG STIU2C00
User ID :	sj97904	Batch NO. :	IUM2504160
Print Interval :	50000 Tablets	Running Time :	13 Hour 22 Min 42 Sec
Total Counter :	1200346	Total Running Time :	2637 Hour 3 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	392	%	Manual ;	20	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		1350000	Tablets			
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		50	Min	Supply Time ;	0.2	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		3.00	kN			
Ejecting Force High Limit :		4.90	kN			
				Stop Condition ;		
HSP :	30.0 %	37.63	kN	No		
HEP :	25.0 %	36.19	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	29.53	kN	Yes 15	Times	
Ref :		28.95	kN			
LCP :	2.0 %	28.37	kN	Yes 15	Times	
LEP :	25.0 %	21.71	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	20.26	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	2.71	kN	Min :	2.56	kN	Punch NO.;	9
SD :	2.00	%	Max :	2.83	kN	Punch NO.;	44
Mean Main Pressure :	29.82	kN	Min :	26.82	kN	Punch NO.;	17
SD :	4.20	%	Max :	32.34	kN	Punch NO.;	44
Filling Depth :	Increase ;	1168	Times	Decrease ;	1125	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	15	RPM	Capacity :	95400	Tablets/hour
Feeder : Status ;	Auto		Speed ;	59	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	8.30	mm	Pre Thickness ;	5.31	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	7.40	mm	Main Thickness ;	4.41	mm
Filling Depth :	10.37	mm	Current Cam :	Cam C 8.5-14mm	
Main Air pressure :	0.805	MPa			
Oil Lubrication status :					
Upper Punch Remain Time (S1):	30	Min			
Lower Punch Remain Time (S2):	19	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.07	kN		
	Max ;	0.11	kN	Max Punch ;	16
Lower Punch :	Average ;	0.07	kN		
	Max ;	0.09	kN	Max Punch ;	2
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	1200346	Tablets			
A.W.C Counter :	1194377	Tablets			
HEP :	616 (0.1%)	Tablets	LEP :	331 (0.0%)	Tablets
GOOD :	1193430 (99.9%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	IBU BP600MG STIU2C00
User ID :	sj97904	Batch NO. :	IUM2504160
Print Interval :	50000 Tablets	Running Time :	13 Hour 22 Min 43 Sec
Total Counter :	1200372	Total Running Time :	2637 Hour 3 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	370	%	Manual ;	23	RPM
Filling Cam :		Cam C		Cam Range :	Min :	6.50 mm
		8.5-14mm			Max :	12.00 mm
Target Quantity :		1350000	Tablets			
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		50	Min	Supply Time ;	0.2	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	1.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		2	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		3.00	kN			
Ejecting Force High Limit :		4.90	kN			
				Stop Condition ;		
HSP :	30.0 %	39.48	kN	No		
HEP :	25.0 %	37.96	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	30.98	kN	Yes 15	Times	
Ref :		30.37	kN			
LCP :	2.0 %	29.76	kN	Yes 15	Times	
LEP :	25.0 %	22.78	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	21.26	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	2	Rotations		Calculation Pass :	2	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	2.13	kN	Min :	2.00	kN	Punch NO.;	9
SD :	2.60	%	Max :	2.24	kN	Punch NO.;	41
Mean Main Pressure :	30.54	kN	Min :	26.02	kN	Punch NO.;	21
SD :	6.00	%	Max :	34.31	kN	Punch NO.;	51
Filling Depth :	Increase ;	427	Times	Decrease ;	324	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	15	RPM	Capacity :	95400	Tablets/hour
Feeder : Status ;	Auto		Speed ;	56	RPM
Pre Upper Punch Position ;	2.99	mm			
Pre Lower Punch Position ;	8.49	mm	Pre Thickness ;	5.50	mm
Main Upper Punch Position ;	2.99	mm			
Main Lower Punch Position ;	7.43	mm	Main Thickness ;	4.44	mm
Filling Depth :	10.46	mm	Current Cam :	Cam C	
Main Air pressure :	0.805	MPa		8.5-14mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	30	Min			
Lower Punch Remain Time (S2):	19	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.07	kN		
	Max ;	0.10	kN	Max Punch ;	42
Lower Punch :	Average ;	0.07	kN		
	Max ;	0.09	kN	Max Punch ;	2
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	1200372	Tablets			
A.W.C Counter :	1194377	Tablets			
HEP :	616 (0.1%)	Tablets	LEP :	331 (0.0%)	Tablets
GOOD :	1193430 (99.9%)	Tablets			