

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	PANTO 40 MG,STKQ1B00
User ID :	mr99799	Batch NO. :	KQM2510140
Print Interval :	50000 Tablets	Running Time :	11 Hour 58 Min 51 Sec
Total Counter :	2201266	Total Running Time :	2972 Hour 55 Min
Station :	Station 1		

Setting Value

Feeder :	Auto ;	75	%	Manual ;	33	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		2750000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		20	Min	Supply Time ;	2.0	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	10.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		3.00	kN			
Ejecting Force High Limit :		4.90	kN			
				Stop Condition ;		
HSP :	30.0 %	41.72	kN	No		
HEP :	25.0 %	40.12	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	32.74	kN	Yes 15	Times	
Ref :		32.10	kN			
LCP :	2.0 %	31.45	kN	Yes 15	Times	
LEP :	25.0 %	24.07	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	22.47	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	2 Rotations			Calculation Pass :	2	Rotations
Empty Punch No. :	None					

Pressure Data

Mean Pre Pressure :	3.70	kN	Min :	3.38	kN	Punch NO.;	55
SD :	3.50	%	Max :	3.98	kN	Punch NO.;	38
Mean Main Pressure :	31.58	kN	Min :	28.68	kN	Punch NO.;	55
SD :	3.50	%	Max :	33.86	kN	Punch NO.;	65
Filling Depth :	Increase ; 202	Times	Decrease ;	212	Times		

PRODUCTION REPORT

Operation Value

Disk Speed :	20	RPM	Capacity :	184800	Tablets/hour
Feeder : Status ;	Auto		Speed ;	15	RPM
Pre Upper Punch Position ;	2.69	mm			
Pre Lower Punch Position ;	4.00	mm	Pre Thickness ;	1.31	mm
Main Upper Punch Position ;	2.69	mm			
Main Lower Punch Position ;	3.60	mm	Main Thickness ;	0.91	mm
Filling Depth :	3.75	mm	Current Cam :	Cam B	
Main Air pressure :	0.745	MPa		4.5-10mm	
Oil Lubrication status :					
Upper Punch Remain Time (S1):	1	Min			
Lower Punch Remain Time (S2):	16	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.17	kN		
	Max ;	0.23	kN	Max Punch ;	39
Lower Punch :	Average ;	0.18	kN		
	Max ;	0.51	kN	Max Punch ;	9
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	2201266	Tablets			
A.W.C Counter :	2185779	Tablets			
HEP :	257 (0.0%)	Tablets	LEP :	427 (0.0%)	Tablets
GOOD :	2185095 (100.0%)	Tablets			

PRODUCTION REPORT

Product Information

Machine Name :	VANTIX P720D	Product Name :	PANTO 40 MG,STKQ1B00
User ID :	mr99799	Batch NO. :	KQM2510140
Print Interval :	50000 Tablets	Running Time :	11 Hour 58 Min 51 Sec
Total Counter :	2201266	Total Running Time :	2972 Hour 55 Min
Station :	Station 2		

Setting Value

Feeder :	Auto ;	70	%	Manual ;	24	RPM
Filling Cam :		Cam B 4.5-10mm		Cam Range :	Min :	2.50 mm
Target Quantity :		2750000	Tablets		Max :	8.00 mm
Air Pressure Low Limit :		0.400	MPa			
Oil Lubrication :						
Upper Punch Interval Time(S1) ;		20	Min	Supply Time ;	2.0	Sec
Lower Punch Interval Time(S2) ;		20	Min	Supply Time ;	10.0	Sec
Powder Supply Time :		60.0	Sec			
Initial Reject Time :		1	Tablets			
Upper Punch Tightness High Limit :		2.00	kN			
Lower Punch Tightness High Limit :		3.00	kN			
Ejecting Force High Limit :		4.90	kN			
				Stop Condition ;		
HSP :	30.0 %	39.62	kN	No		
HEP :	25.0 %	38.09	kN	Yes 10	Rotations 15	Tablets
HCP :	2.0 %	31.08	kN	Yes 15	Times	
Ref :		30.47	kN			
LCP :	2.0 %	29.86	kN	Yes 15	Times	
LEP :	25.0 %	22.85	kN	Yes 10	Rotations 15	Tablets
LSP :	30.0 %	21.33	kN	No		
SD limit :	45.0 %			Yes		
Pre HSP		40.00	kN	Yes		
Mean Calculation range :	1	Rotations		Calculation Pass :	1	Rotations
Empty Punch No. :	N					

Pressure Data

Mean Pre Pressure :	3.74	kN	Min :	3.27	kN	Punch NO.;	32
SD :	4.80	%	Max :	4.17	kN	Punch NO.;	38
Mean Main Pressure :	30.52	kN	Min :	27.03	kN	Punch NO.;	66
SD :	4.00	%	Max :	33.06	kN	Punch NO.;	38
Filling Depth :	Increase ;	283	Times	Decrease ;	290	Times	

PRODUCTION REPORT

Operation Value

Disk Speed :	20	RPM	Capacity :	184800	Tablets/hour
Feeder : Status ;	Auto		Speed ;	14	RPM
Pre Upper Punch Position ;	2.70	mm			
Pre Lower Punch Position ;	4.00	mm	Pre Thickness ;	1.30	mm
Main Upper Punch Position ;	2.75	mm			
Main Lower Punch Position ;	3.60	mm	Main Thickness ;	0.85	mm
Filling Depth :	3.65	mm	Current Cam :	Cam B 4.5-10mm	
Main Air pressure :	0.745	MPa			
Oil Lubrication status :					
Upper Punch Remain Time (S1):	1	Min			
Lower Punch Remain Time (S2):	16	Min			
Lower Head Remain Time (S3):	0	Min			
Powder Status :	Disable		Dust Collector :	Off	
Initial Reject :	Off		Buzzer :	Off	

Tightness

Upper Punch :	Average ;	0.16	kN		
	Max ;	0.22	kN	Max Punch ;	29
Lower Punch :	Average ;	0.18	kN		
	Max ;	0.51	kN	Max Punch ;	9
Ejection Force :	Average ;	0.00	kN		
	Max ;	0.00	kN	Max Punch ;	0

Tablet Data (N/A)

Total Counter :	2201266	Tablets			
A.W.C Counter :	2185779	Tablets			
HEP :	257 (0.0%)	Tablets	LEP :	427 (0.0%)	Tablets
GOOD :	2185095 (100.0%)	Tablets			